# **OPERATING MANUAL**

Model/Series: CCM Number: 040-581 GB Version: 2019-02



# **Bearingless Rotating Unions**



# **Series**

# **CCM for PRIMETALS**

Model	
M40	
M46	
M60 D60	
D60	

for use of water as medium.

Rev. C ©DEUBLIN



Model/Series: CCM Number: 040-581 GB Version: 2019-02

# Content

1	For your Safety	3	
	1.1 Intended Use		
	1.1.1 Application one-way version (Mono)	3	
	1.2 Misuse		
	1.3 Safety Instructions		
	1.3.1 Hazards due to hot surfaces		
	1.3.2 Hazards by faulty installation		
0	1.4 Structure of Pictograms		
2	Information as to this Manual		
3	Information on the Name Plate	6	
4	Information on the Design		
	4.1 Components of Rotating Unions (Mono/Duo)		
	4.2 Fit, Shape and Positional Tolerances		
	4.3 Mounting Direction of Bushing		
	4.4 Prepare Installation of Rotating Union		
_	4.5 Ensure Drainage of Leaking Medium		
5	Installation	8	
6	Information on the Operation	8	
7	Storage	9	
8	Maintenance	9	
	8.1 Maintenance Intervals	9	
	8.2 Daily Inspection	9	
9 Trouble Shooting			
	9.1 Potential Causes for Errors and their Elimination		
	9.2 Pack Rotating Union for Transport	11	
10	Disposal	12	
	10.1 Dispose of Packaging		
	10.2 Dispose of Rotating Union		
11	Spare Parts_	12	



Model/Series: CCM Number: 040-581 GB Version: 2019-02

# 1 For your Safety

This chapter provides information on the safe handling of DEUBLIN Bearingless Rotating Unions.

- ☐ For your own safety and the safety of other people read this operating manual carefully and completely prior to working on or with *DEUBLIN* rotating unions.
- ☐ This operating manual exclusively describes the rotating unions of the manufacturer *DEUBLIN*. In the further description/explanation the name "*DEUBLIN*" is left out for a better readability.
- ☐ This operating manual is a material part of the specified rotating unions. The operator is responsible for the personnel to take note of this manual.
- ☐ Always use the latest version of the operating manual, available under www.deublin.eu.
- ☐ The operator of the rotating unions shall not make any modifications or attachments to and retrofitting of the rotating union without the manufacturer's consent.
- ☐ Please follow the additional instruction "Installation" for a secure and correct installation of the rotating union. The installation instruction is included with the delivered union.

#### 1.1 Intended Use

The rotating unions of series CCM supply the feeding of water for continuous casting plants in the steel industry. The fed water cools the rollers.

Model	Q <sub>max.</sub> (I/min)	max. pressure (bar)	N <sub>max.</sub> GMU (min <sup>-1</sup> )	Temperature range (°C)	
M40 Mono	41		20		
M46 Mono	64	16		3 up to 120 <sup>1)</sup>	
M60 Mono	114	10			
D60 Duo	75				

<sup>&</sup>lt;sup>1)</sup> If you need the rotating unions for higher temperatures of the medium, consult with *DEUBLIN*.

The rotating unions of CCM series are designed for non-potentially explosive environments and non-combustible media.

For information on the range of use of the rotating unions, please refer to the catalogue and/or the model-specific installation drawing.

Depending on the connection, the rotating unions of CCM series can be used as one-way or two-way version. The model D60 can only be used as two-way version.

# 1.1.1 Application one-way version (Mono)





Fig. 1: Schematic diagram one-way version (Mono – outside installation)

One one-way version of the rotating union is mounted at each of the two ends of the roller. The rotating union **(A)** conveys the medium flow into the roller. The rotating union **(B)** conveys the medium flow into the piping system of the machine.



Model/Series: CCM Number: 040-581 GB Version: 2019-02

## 1.1.2 Application two-way version (Duo)



At one end of the roller a rotating union is installed which conveys the medium flow in the roller and then in the piping system of the machine.

Fig. 2: Schematic diagram two-way version (Duo)

#### 1.2 Misuse

This chapter provides information on known misuse of rotating unions of the CCM series.

The rotating unions are not suitable for the areas and applications described herein. Use in such areas or for such applications constitutes a misuse endangering people and machines and is therefore prohibited.

#### Prohibition for the following areas:

## □ Potentially explosive rooms

The rotating unions of the CCM series shall not be used in potentially explosive rooms, as they are not approved for the requirements in potentially explosive rooms. Operation in such rooms may cause explosions.

#### Outdoor operation

Inadequate protection against weather conditions can result in premature failure.

#### Prohibition for the following applications:

#### ☐ Conveying of combustible media or hydrocarbons

Combustible media or hydrocarbons may ignite or cause explosions.

#### ☐ Food

Food, cleaning and disinfectant residues cannot be removed from the rotating unions. People may suffer poisoning.

## ☐ Connection to a piping system with excessive pressure

If excessive pressure is applied to the rotating unions, the connections may become leaky and personal injury or property damage may be caused by the escaping medium.

#### ☐ Conveying of media which are too hot

If the media exceed the maximum admissible temperature for the rotating union, the seals can be damaged which may result in leaky rotating unions and personal injury or property damage.

### ☐ Operation without a medium (dry run)

If the rotating unions are operated without a medium, the sealing surface of the rotating unions might fail prematurely.

# ☐ Application in ambient temperatures/with media temperatures below 3°C

Rotating unions may be damaged if they are operated at temperatures (ambient or media) below 3 °C.

#### □ Conveying of vapour

Vapour damages the rotating union. Escaping vapour may injure people seriously.



Model/Series: CCM Number: 040-581 GB Version: 2019-02

	Operation	at the	maximum	speed	and with	maximum	pressure
--	-----------	--------	---------	-------	----------	---------	----------

Speed and pressure must be adjusted to each another so that the rotating unions are not damaged or fail prematurely (see model-specific installation drawing).

This list is not comprehensive and will be updated with results from product observation.

## 1.3 Safety Instructions

This chapter provides information on the hazards through rotating unions.

#### 1.3.1 Hazards due to hot surfaces

The rotating unions are heated by the temperature of the medium. Skin contact with heated rotating unions can cause injuries.

- Use safety gloves protecting against heat when handling the rotating union.
- ☐ Attach a clearly visible danger sign visibly on/next to the rotating union in order to warn of danger.

## 1.3.2 Hazards by faulty installation

In case of faulty installation of the rotating unions, the connections and O-rings of the rotating unions may become leaky. The medium may escape. Depending on the medium, people may be injured and components of the machine may be damaged.

- ☐ Before installing the rotating union ensure that no feed pressure and no residual pressure is applied to the pipeline system of the machine.
  - Please follow the additional instruction "Installation" for a secure and correct installation of the rotating union. The installation instruction is included with the delivered union.
- ☐ Prior to installation, make sure that the O-rings are positioned correctly in the recesses of the rotating union.
- Make sure the fixings of the rotating union are tightened in the correct sequence.
- ☐ Rotating Unions with leakage line: Install the rotating union in a way that the leaking medium can be carried away securely downward at the lowest point and that the drain line shows a fall (min. 15°).



Model/Series: CCM Number: 040-581 GB Version: 2019-02

# 1.4 Structure of Pictograms

This chapter provides information on the meaning of the pictograms used in the manual.



## Warning

Potentially dangerous situation, which may result in death or serious injury.



#### Note

Potentially harmful situation in which the product or surrounding objects can be damaged.



#### **Application notes**

and other useful information.

# 2 Information as to this Manual

The copyright as to this manual remains with DEUBLIN. Subject to changes!

- ☐ You can download the latest version of this manual under www.deublin.eu.
- Always use the latest version of the operating manual.

# 3 Information on the Name Plate

Model number



DEUBLIN's internal identification / date of manufacture

MADE IN <<country of manufacture>>

PRIMETALS service contact

Fig. 3: Name plate

The model number corresponds to the order number.



# **DEUBLIN**<sup>®</sup> Operating Manual

Model/Series: CCM Number: 040-581 GB Version: 2019-02

# 4 Information on the Design

This chapter provides information as to which items have to be observed in the design in order to have a positive effect on the service life of the rotating union.




You can obtain the drawings of the rotating unions from *DEUBLIN* to integrate the rotating union in your drawing.

You will require the model-specific installation drawing of your rotating unions to implement it into your design and to operate the rotating unions in a safe manner.

The model-specific installation drawing of the respective rotating union contains e.g.:

- authorized operating data
- design of customer's interface
- torque moments of the union
- tolerances

# 4.1 Components of Rotating Unions (Mono/Duo)



Figures 4 and 5 show the most important components of a rotating union. The models of CCM series may deviate from the figures. All models feature the same design and are comparable to the shown figures.

Fig. 4: One-way version (Mono)




Fig. 5: Two-way version (Duo)

# 4.2 Fit, Shape and Positional Tolerances

Functioning of the rotating unions is only ensured, if you observe the specifications of *DEUBLIN* regarding the design of fits, shape and positional tolerances. If you do not observe them, O-rings etc. may be damaged. The medium may escape. Corresponding information can be found in the technical drawing of the rotating union.

☐ Make sure that all specifications by *DEUBLIN* on the installation of the rotating union in your machine are observed.



Model/Series: CCM Number: 040-581 GB Version: 2019-02

# 4.3 Mounting Direction of Bushing

The bushing is inserted in the bore of the roller. It transmits the rotating movement of the roller to the rotor of the rotating union. For this purpose, the bushing is provided with a drive pin. Depending on the type of bushing, the drive pin is installed on the bushing axially or radially. The rotating union is slipped on the drive pin.

☐ Consider the mounting direction of the bushing in the design in order to be able to slip the rotating union on the drive pin when installing it.

# 4.4 Prepare Installation of Rotating Union

Sharp edges of the bore of the journal may damage the O-rings of the rotating union.

☐ Provide the bore of the journal with a chamfer of 30° in order to prevent the O-rings from being damaged when pressing them in.

## 4.5 Ensure Drainage of Leaking Medium

The rotating unions are provided with a vent hole. Complete draining of leaking medium can only be ensured, if the vent hole is in 6 o'clock position.

☐ Always position the rotating unions in a way that the vent hole is always in 6 o'clock position (at the lowest point).

# 5 Installation

The union installation is described in an additional manual which is supplied with each rotating union. Please follow the additional instruction "Installation" for a secure and correct installation of the rotating union. The instruction "Installation" is available online under www.deublin.eu.

- ☐ Ensure that the person installing the rotating union receives the following information:
  - Position and location of the rotating union in the machine
  - Information on the media
  - Position of leakage line
  - model-specific installation drawing

# 6 Information on the Operation



## Damage to components due to missing lubrication

The axial face seals of the rotating unions are lubricated by the medium. If the rotating unions are operated without medium, they are not lubricated and will thus be damaged.

- ☐ Ensure that the rotating unions are operated with a medium.
- Switch off the plant/machine, if the rotating unions are operated without medium.



#### Damage by cold media

If you convey a medium with a temperature below 3 °C through the rotating union, the latter will be damaged.

☐ Use the rotating unions only with media with a temperature above 3 °C.



Model/Series: CCM Number: 040-581 GB Version: 2019-02

# 7 Storage



#### Damage of component due to incorrect storage

If you store the rotating unions incorrectly, they become leaky or get damaged.

- ☐ Store the rotating unions in a dry space as from 3 °C to 40 °C.
- ☐ Store rotating unions for two years at the most.

## 8 Maintenance

This chapter provides information on how to extend the service life of the rotating unions by means of maintenance.

Regular inspections are required if malfunctions of the *DEUBLIN* rotating union can cause risk to health or environment.

#### 8.1 Maintenance Intervals

Rotating unions of CCM series are maintenance-free.



#### Risk of injury due to hot surfaces

The rotating unions are heated by the temperature of the medium.

When touching this heated rotating union, severe injuries may be caused.

- ☐ Before starting to work on the rotating unions, allow the machine to cool.
- ☐ Depending on the application of the rotating union, use gloves protecting against heat.



# Damage of component due to old bushing

If you operate an old bushing with a new rotating union, the latter may be damaged.

☐ Always replace rotating union and bushing.

# 8.2 Daily Inspection

Check the rotating unions for tightness.



### Risk of injuries due to applied line pressure

If you have to work on the rotating union and feed pressure of the medium is applied or there is residual pressure in the piping system of the machine, the medium can escape under pressure when releasing the connections. You and other people may suffer severe injuries.

- Ensure that no feed pressure is applied.
- ☐ Ensure that there is no residual pressure in the piping system.



Model/Series: CCM Number: 040-581 GB Version: 2019-02




Fig. 6: Inspect visually

During operation of the machine, leakages may occur at the connecting flange depending on the requirements to the rotating unions.

☐ Carry out daily visual inspections in order to check whether leakages occurred at the connections (see arrows).

If you detect leakages:

- 1. Stop the machine.
- 2. Replace the defective hoses by new ones.
- 3. Seal leaking connections.
- If the rotating union is worn and leaks, replace it by a new one. In doing so, always replace rotating union and bushing. Repair kits for various models can be obtained from DEUBLIN.

# 9 Trouble Shooting

This chapter provides the following information:

- 1. Which errors may occur?
- 2. What can be the cause of the error?
- 3. How can you eliminate this error?

#### 9.1 Potential Causes for Errors and their Elimination



## Risk of injuries due to applied line pressure

If you have to work on the rotating union and feed pressure of the medium is applied or there is residual pressure in the piping system of the machine, the medium can escape under pressure when releasing the connections. You and other people may suffer serious injuries.

- ☐ Ensure that no feed pressure is applied.
- ☐ Ensure that there is no residual pressure in the piping system.



# - *DEUBLIN*<sup>◦</sup> Operating Manual

Model/Series: CCM Number: 040-581 GB Version: 2019-02

Error	Potential causes	Elimination
Rotating union is leaky after installation	Incorrect installation	<ol> <li>Stop the machine.</li> <li>Ensure that the connections are sealed according to the manual "Installation".</li> <li>Make sure that all seal faces are clean.</li> <li>Make sure that the O-rings are in the correct position.</li> </ol>
	Seal faces of the rotating union are damaged	Pack rotating union.     Send rotating union to DEUBLIN for overhaul/
	Rotating union is defective	service.
Rotating union leaks before the end of the expected service life.	The rotating union is not designed for the case of application.	<ol> <li>Ensure that the correct <i>DEUBLIN</i> Rotating Union is used.</li> <li>Contact <i>DEUBLIN</i> if required.</li> </ol>
	The medium shows impurities.	<ol> <li>Shut down machine.</li> <li>Drain medium.</li> <li>Send rotating union to DEUBLIN for overhaul/ service, if required.</li> <li>Flush the piping system of the machine.</li> <li>Mount new filter.</li> <li>Fill in new medium.</li> </ol>
No flow through rotating union.	Incorrect position of rotating union, incorrect installation of flange.	<ol> <li>Shut down machine.</li> <li>Drain medium.</li> <li>Release flange of rotating union, align feed and return conduit, observe coded screw position and use correct number of screws.</li> </ol>

## 9.2 Pack Rotating Union for Transport

The rotating union has to be protected against mechanical impact and humidity during transport to ensure that the rotating union will arrive at *DEUBLIN* without being damaged.

- 1. Dismount the rotating union in reverse order of the installation (see Installation).
- 2. Ensure that the rotating union is free from the respective media.
- 3. Use a cardboard box which is suitable for the weight of the rotating union.
- 4. Cushion the ground of the cardboard box with a soft material, e.g. air bubble film.
- 5. Wrap the rotating union with a soft material, e.g. air bubble film.
- 6. Ensure that no packing material or dirt can penetrate the opening of the rotating union.
- 7. Position the rotating union in the middle of the cardboard box.
- 8. Fill the free space around the rotating union with newspaper or another suitable material.
- 9. Close the cardboard box by means of tape.



Model/Series: CCM Number: 040-581 GB Version: 2019-02

# 10 Disposal

## 10.1 Dispose of Packaging

☐ Dispose of the packaging (cardboard box and plastics) according to the national standards, regulations and directives.

# 10.2 Dispose of Rotating Union

Mainly, the rotating unions consist of metals, which can be reused within the reclamation of scrap. Decontaminate unions / parts and dispose of in an "Environmentally Friendly" way.

- ☐ Dismount the rotating union in reverse order to the installation (see Installation).
- Flush the rotating union.
- Collect the dirty rinsing water.
- ☐ Dispose of the collected rinsing water according to the national standards, regulations and directives.
- ☐ Please observe the instructions of the media manufacturer.
- ☐ Dispose of the rotating union according to the national standards, regulations and directives.

In case of repair, DEUBLIN disposes of all used parts.

# 11 Spare Parts

The rotating unions have a limited service life and include wearing parts. Wearing parts are excluded from the warranty. All static and dynamic sealing elements of a component are considered wearing parts, as well as ball bearings.

Repair kits are available for several models of the rotating unions and can be obtained from *DEUBLIN*. Please ask your *DEUBLIN* Service.

You need special tools and repair instructions for repair of the rotating unions which can be obtained from *DEUBLIN* as well.



## Note

If you do not want to repair your rotating union on your own, *DEUBLIN* will be pleased to help you. If requested, *DEUBLIN* will exchange all wearing parts and clean all components of the rotating union. Before repaired rotating unions leave the premises, they will be subjected to an operational check. The repaired rotating union is returned with a standard "*DEUBLIN* Warranty" valid for 12 months.

# **32019** DEUBLIN GmbH | Florenz-Allee 1 | 55129 Mainz | Alle Rechte vorbehalten

#### Reliability

Many years' experience, ongoing liaison with customers, innovations sourced inhouse and from suppliers place DEUBLIN in a position providing reliable Rotating Unions at the highest level.

When it comes to concrete applications, maximum service life is guaranteed by matching the sealing to the respective medium.

The service life is also equally maximized by maintaining cleanliness when storing and handling the Rotating Union and by adhering to the guidelines issued by *DEUBLIN* in respect of the conditions on the customer's premises.

#### **EUROPE**

#### **DEUBLIN** Germany

Florenz-Allee 1 55129 Mainz, Germany Phone: +49 6131-49980 e-mail: info@deublin.de

# **DEUBLIN** Italy

Via Guido Rossa 9 - Loc. Monteveglio 40053 Comune di Valsamoggia (BO), Italy Phone: +39 051-835611 +39 051-832091 Fax:

e-mail: info@deublin.it

# **DEUBLIN** Austria

Lainzer Straße 35 1130 Wien, Austria Phone: +43 1-8768450 +43 1-876845030 e-mail: info@deublin.at

#### **DEUBLIN** France

61 Bis, Avenue de l'Europe Z.A.C de la Malnoue, Emerainville 77436 Marne-la-Vallée Cedex 2, France Phone: +33 1-64616161

+33 1-64616364 e-mail: service.client@deublin.fr

# **DEUBLIN** Poland

ul. Bierutowska 57-59 51-317 Wrocław, Poland Phone: +48 71-3528152 +48 71-3207306 e-mail: info@deublin.pl

# **DEUBLIN** Russia

5ya yl. Sokolinoi gori, 18, bld 2, 1st floor Moscow, 105275, Russia Phone: +7 495-647 1434 e-mail: info@deublinrussia.ru

#### **DEUBLIN** Spain

C/ Lola Anglada, 20 local 1 08228 Terrassa, Spain Phone: +34 93-221 1223 e-mail: deublin@deublin.es

#### **DEUBLIN** United Kingdom

6 Sopwith Park, Royce Close, West Portway

Andover SP10 3TS, UK Phone: +44 1264-33 3355 Fax: +44 1264-33 3304 e-mail: info@deublin.co.uk

#### AMERICA

#### **DEUBLIN** USA

DEUBLIN Brazil

2050 Norman Drive Waukegan, IL 60085-6747 U.S.A

Phone: +1 847-689 8600 Fax: +1 847-689 8690

# e-mail: customerservice@deublin.com

Rua Fagundes de Oliveira, 538 - Galpão A11

Piraporinha

09950-300 - Diadema - SP - Brasil

Phone: +55 11-2455 3245 Fax: +55 11-2455 2358

e-mail: deublinbrasil@deublinbrasil.com.br

# **DEUBLIN** Mexico

Norte 79-A No. 77, Col. Claveria 02080 Mexico, D.F.

Phone: +52 55-5342 0362 Fax: +52 55-5342 0157

e-mail: deublinmexicocs@deublin.com

#### **ASIA**

#### **DEUBLIN** China

No. 2, 6th DD Street DD Port Dalian, 116620, China Phone: +86 411-8754 9678 +86 411-8754 9679 e-mail: info@deublin.cn

#### Shanghai Branch Office Room 15A07, Wangjiao Plaza

No. 175 East Yan'an Road, Huangpu District

Shanghai 200002

Phone: +86 21-5298 0791 Fax: +86 21-5298 0790 e-mail: info@deublin.cn

# **DEUBLIN** Asia Pacific

51 Goldhill Plaza #17-02 Singapore 308900 Phone: +65 6259-92 25 +65 6259-97 23 Fax: email: deublin@singnet.com.sg

#### **DEUBLIN** Japan

2-13-1, Minamihanayashiki, Kawanishi City

Hyogo 666-0026, Japan Phone: +81 72-757 0099 +81 72-757 0120

e-mail: customerservice@deublin-japan.co.jp

2-4-10-3F, Ryogoku, Sumida-ku Tokyo 130-0026, Japan Phone: +81 35-625 0777 +81 35-625 0888

e-mail: customerservice@deublin-japan.co.jp

1-9-2-4F, Mikawaanjo-cho, Anjo City

Aichi 446-0056, Japan Phone: +81 566-71 4360 Fax: +81 566-71 4361

e-mail: customerservice@deublin-japan.co.jp

#### **DEUBLIN** Korea

Star Tower #1003, Sangdaewon-dong 223-25, Jungwon-gu, Seongnam-si, Gyeonggi-do,

South Korea

Phone: +82 31-8018 5777 +82 31-8018 5780

e-mail: customerservice@deublin.co.kr